



# Leadshine

## Datasheet of the High Voltage Easy Servo Drive

### *ES-DH1208*



**70-130VAC, 8.0A Peak, Closed-loop, No Tuning**

Version 1.4

<http://www.Leadshine.com>

<http://www.Leadshineusa.com>

©2013 Leadshine Technology Co., Ltd.

## Features

- I Hybrid servo control technology to combine advantages of open-loop stepper systems and brushless servo systems
- I Closed-loop controls to eliminate lose of steps, stall or movement synchronization
- I High starting torque and quick response
- I Smooth motor movement with no vibration
- I Excellent respond time, quick acceleration, and very high high-speed torque (30% over open-loop)
- I Load-dependent dynamic current output from drive to motor to significantly motor heating deduction
- I Input voltage from 70 to 130 VAC; MAX 8.0A peak current output from drive to motor
- I Micro step resolution value from 200-51,200 (increased by 1) via software configuration
- I Isolated control inputs of Pulse, Direction and Enable
- I No tuning for plug and play setup
- I On-board HMI for easy setup and configuration
- I In-position and fault outputs to external motion controllers for complete system controls.
- I Over voltage, over-current, and position-error protection
- I Servo control for stepper motors with encoders up to NEMA 42

## Description

By taking direct 110 / 120 or 220 / 230 VAC input, Leadshine ES-DH series high voltage easy servo drives can power large NEMA 34 and 42 easy servo motors and offer huge torque to applications with motion control systems.

Leadshine ES-DH series easy servo drives are based on the latest DSP technology and Leadshine's advanced control algorithm of combing brushless servo and stepper systems. They are featured with closed position loop, offering huge torque, excellent acceleration & quick response, no torque reservation, high standstill stiffness, extra low noise & heating, smooth motor movement, no hunting, no overshooting for almost zero settling time, and no tuning for almost all applications.

## Applications

Due to combining the features of both brushless servo drives and stepper drives, Leadshine ES-DH series easy servo drives are suitable for both upgrading conventional stepper systems, and replacing brushless servo systems which have closed loop and high torque requirements.

Leadshine ES-DH series easy servo drives can also be implemented as high performance open loop stepper drives with direct 110 / 120 and / or 220 /230 VAC input.

Leadshine ES-DH easy servo drives and matching easy servo motors have been successfully implemented by many OEM clients in applications such as CNC routers, plasma, milling machines, engravers, packaging machines, printing equipments.

## Specifications

### Electrical Specifications


|                                    |   |
|------------------------------------|---|
| Parameters                         | ES-DH1208                                 |
| Operating Voltage                  | 70 - 130 VAC                              |
| Maximum Continuous Current         | 8.0 A                                     |
| MAX Step Frequency                 | 200KHz or 500KHz (Software Configuration) |
| Step, Direction and Enable Voltage | 5 – 24 V                                  |
| Logic Signal Input Current         | 7 – 20 mA                                 |

### Control Specifications

|                         |                                     |
|-------------------------|-------------------------------------|
| Parameters              | ES-DH1208                           |
| Command Input           | Step/Direction, CW/CCW              |
| Enable/Disable Input    | Differential                        |
| Alarm Signal Output     | Isolated OC Output                  |
| Configuration Interface | On-board HMI or RS232 communication |
| Regeneration Resistor   | No                                  |

### Mechanical Specifications


|            |                     |
|------------|---------------------|
| Parameters | ES-DH1208           |
| Size       | 180mm * 140mm* 70mm |
| Weight     | 1500 g              |



### Operating Environment

|                     |                                   |
|---------------------|-----------------------------------|
| Cooling             | Natural cooling or Forced cooling |
| Ambient Temperature | 0 – 40 °C                         |
| Humidity            | 40% RH to 90% RH, No Condensation |
| Vibration           | 5.9 m/s <sup>2</sup> MAX          |
| Storage Temperature | -20 °C to 80 °C                   |

### Drive Appearance and Interfaces



## Connectors and Pin Assignments

| CN1 – Control Signal Connector |      |     |  |
|--------------------------------|------|-----|--|
| D-Sub, 26 Pin, Female          |      |     |  |
| Pin                            | Name | I/O | Description  |
| 1                              | NC   | -   | No connection.   |
| 2                              | NC   | -   | No Connection.   |
| 3                              | PUL+ | I   | Pulse signal: In single pulse (pulse/direction) mode, this input represents pulse signal, each rising or falling edge active (software configurable); In double pulse mode (software configurable), this input represents clockwise (CW) pulse, active both at high level and low level. 5-24V when PUL-HIGH, 0-0.5V when PUL-LOW. For reliable response, pulse width should be longer than 2.5uS(200K bandwidth) or 1uS(500K bandwidth)                     |
| 4                              | PUL- | I   |  |
| 5                              | DIR+ | I   | Direction Signal: In single-pulse mode, this signal has low/high voltage levels, representing two directions of motor rotation. In double-pulse mode (software configurable), this signal is counter-clock (CCW) pulse, active both at high level and low level. For reliable motion response, DIR signal should be ahead of PUL signal by 5μs at least. 5-24V when DIR-HIGH, 0-0.5V when DIR-LOW. The direction signal's polarity is software configurable. |
| 6                              | DIR- | I   |  |
| 7                              | ALM+ | O   | Alarm Signal: OC (Open Collector) output signal, activated when one of the following protection is activated: over-voltage, over current, braking error and position following error. They can sink or source MAX 100mA current at 5V. The active impedance of alarm signal is software configurable.  |
| 8                              | ALM- | O   |  |
| 9                              | NC   | -   | No connection.   |
| 10                             | NC   | -   | No connection.   |
| 11                             | ENA+ | O   | Enable Signal: This signal is used for enabling/disabling the driver. By default, high level (NPN control signal) for enabling the driver and low level for disabling the driver. It is usually left UNCONNECTED (ENABLED). Please note that the PNP and Differential control signals are on the contrary, namely Low level for enabling. The active level of ENA signal is software configurable.   |
| 12                             | ENA- | O   |  |
| 13                             | NC   | -   | No connection.   |
| 14                             | NC   | -   | No connection.   |
| 15                             | NC   | -   | No connection.   |
| 16                             | NC   | -   | No connection.   |
| 17                             | NC   | -   | No connection.   |
| 18                             | NC   | -   | No connection.   |
| 20                             | NC   | -   | No connection.   |
| 21                             | NC   | -   | No connection.   |
| 22                             | NC   | -   | No connection.   |

*Connectors and Pin Assignments (Continued)*

| CN1 – Control Signal Connector |      |     |                            |
|--------------------------------|------|-----|----------------------------|
| D-Sub, 26 Pin, Female          |      |     |                            |
| Pin                            | Name | I/O | Description                |
| 23                             | NC   | -   | No connection.             |
| 24                             | NC   | -   | No connection.             |
| 25                             | NC   | -   | No connection.             |
| 26                             | NC   | -   | No connection.             |
| 27                             | NC   | -   | No connection.             |
| 28                             | NC   | -   | No connection.             |
| 29                             | NC   | -   | No connection.             |
| 30                             | NC   | -   | No connection.             |
| 31                             | NC   | -   | No connection.             |
| 32                             | NC   | -   | No connection.             |
| 33                             | NC   | -   | No connection.             |
| 34                             | NC   | -   | No connection.             |
| 35                             | NC   | -   | No connection.             |
| 36                             | NC   | -   | No connection.             |
| 37                             | NC   | -   | No connection.             |
| 38                             | NC   | -   | No Connection.             |
| 39                             | NC   | -   | No connection.             |
| 40                             | NC   | -   | No connection.             |
| 41                             | NC   | -   | No connection.             |
| 42                             | NC   | -   | No connection.             |
| 43                             | NC   | -   | No connection.             |
| 44                             | NC   | -   | No connection.             |
|                                | FG   | -   | Ground Terminal for shield |

**Connectors and Pin Assignments (Continued)**

| CN2 – Feedback Signal (Encoder) Connector |      |     |  |
|---|------|-----|--|
| HDD15, 15Pin, Female                      |      |     |  |
| Pin                                       | Name | I/O | Description                              |
| 1   | EA+  | I   | Encoder A+ input                         |
| 2   | EB+  | I   | Encoder B+ input                         |
| 3   | EGND | I/O | +5V output return ground                 |
| 4   | NC   | I   | No Connection.                           |
| 5   | NC   | I   | No Connection.                           |
| 6   | FG   | I   | Ground terminal for shield               |
| 7   | NC   | I   | No Connection                            |
| 8   | NC   | I   | No Connection                            |
| 9   | NC   | I   | No Connection.                           |
| 10  | NC   | I   | No Connection.                           |
| 11  | EA-  | I   | Encoder A- input                         |
| 12  | EB-  | I   | Encoder B- input                         |
| 13  | +5V  | O   | +5V power output for encoder, MAX 100mA. |
| 14  | NC   | I   | No Connection.                           |
| 15  | NC   | I   | No Connection.                           |

| CN4 – RS232 Communication Connector |      |  |  |
|-------------------------------------|------|--|--|
| RS232                               |      | Can be connected to PC for drive configuration or servo tuning. Recommended twisted shielded cable and cable length < 2 meter. |  |
| Pin                                 | Name | I/O  | Description  |
| 1                                   | GND  | GND  | Ground.  |
| 2                                   | TxD  | O  | RS232 transmit.  |
| 3                                   | +5V  | O  | Reserved +5V power output ( Note: Do not connect it to RS232 port) |
| 4                                   | RxD  | O  | RS232 receive.   |
| 5                                   | NC   | -  | NC   |
| 6                                   | NC   | -  | NC   |


*Connectors and Pin Assignments (Continued)*

| Power Connector: |      |     |   |
|------------------|------|-----|---|
| Pin              | Name | I/O | Description                                 |
| 1                | L    | I   | Power supply input connected to 70- 130VAC. |
| 2                | N    | I   |   |
| 3                | PE   | -   | Case ground                                 |
| 4                | NC   | -   | No connection.                              |
| 5                | NC   | -   | No connection.                              |


| Motor Connector |      |     |                |
|-----------------|------|-----|----------------|
| Pin             | Name | I/O | Description    |
| 1               | A+   | O   | Motor phase A+ |
| 2               | A-   | O   | Motor phase A- |
| 3               | B+   | O   | Motor phase B+ |
| 4               | B-   | -   | Motor phase B- |
| 5               | PE   | -   | Case ground    |
| 6               | NC   | -   | No connection  |

## Connector Pin-Out

### CN1 – Control Signal Connector




### CN2 – Feedback Signal Connector




### Connector Pin-Out (Continued)


#### CN4 – RS232 & RS485 Connector




#### CN5 –Power Connector



#### CN6 – Motor Connector




### Easy Servo Motors

|                                    | ES-MH23480 | ES-MH234120 | Wiring Diagram  |
|------------------------------------|------------|-------------|---|
| Step Angle (°)                     | 1.8        | 1.8         |  |
| Holding Torque (N.m)               | 8.0        | 12.0        |   |
| Phase Current (A)                  | 5.0        | 5.5         |   |
| Phase Resistance (Ohm)             | -          | -           |   |
| Phase Inductance (mH)              | -          | -           |   |
| Shaft Inertia (g.cm <sup>2</sup> ) | -          | -           |   |
| Weight (Kg)                        | 4.0        | 5.6         |   |
| Encoder (lines / Rev.)             | 1000       | 1000        |   |

### Motor Encoder Cable Pin-Out


ES-MH23480, ES-MH234120

| Pin | Name | Wire Color | I/O | Description       |
|-----|------|------------|-----|-------------------|
| 1   | EA+  | Black      | O   | Channel A+ output |
| 2   | VCC  | Red        | I   | +5V power input   |
| 3   | GND  | White      | GND | Ground            |
| 11  | EB+  | Yellow     | O   | Channel B+ output |
| 12  | EB-  | Green      | O   | Channel B- output |
| 13  | EA-  | Blue       | O   | Channel A- output |



## Motor Encoder Extension Cable

### CABLEG-BMXXM



#### Pin Assignments

| A: HDD15 Female | Wire Color | B: HDD15 Male | Name | Description     |
|-----------------|------------|---------------|------|-----------------|
| Pin             |            | Pin           |      |                 |
| 1               | Black      | 1             | EA+  | Channel A+      |
| 2               | Red        | 13            | VCC  | +5V power input |
| 3               | White      | 3             | GND  | +5V GND         |
| 11              | Yellow     | 2             | EB+  | Channel B+      |
| 12              | Green      | 12            | EB-  | Channel B-      |
| 13              | Blue       | 11            | EA-  | Channel A-      |


#### Cable Length

| Part Number   | L     | Matching Motor          |
|---------------|-------|-------------------------|
| CABLEG-BM3M0  | 3.0m  | ES-MH23480, ES-MH234120 |
| CABLEG-BM8M0  | 8.0m  |                         |
| CABLEG-BM10M0 | 10.0m |                         |
| CABLEG-BM12M0 | 12.0m |                         |

Note: The encoder extension cable must be connected between the ES-MH2 motor and the ES-DH1208. You can not connect the motor's encoder cable to the ES-DH1208 directly.

## Motor Power Extension Cable

### CABLEH-RZXXM



### Motor Power Extension Cable (Continued)


#### Pin Assignments

| A   | B              | Name | Description    |
|-----|----------------|------|----------------|
| Pin | Wire Color     |      |                |
| 1   | Blue           | B-   | Motor Phase B- |
| 2   | Red            | A-   | Motor Phase A- |
| 3   | Black          | A+   | Motor Phase A+ |
| 4   | Yellow / Green | B+   | Motor Phase B+ |

#### Cable Length


| Part Number   | L     | Matching Motor          |
|---------------|-------|-------------------------|
| CABLEH-RZ3M0  | 3.0m  | ES-MH23480, ES-MH234120 |
| CABLEH-RZ5M0  | 5.0m  |                         |
| CABLEH-RZ10M0 | 10.0m |                         |

### Typical Connections




Connections to controller of differential output

## Typical Connections (Continued)



Connection to controller of sinking output



Connection to controller of sourcing output